


# TECHNICAL DATA SHEET

W.DS.033 (FB-NC SERIES) REV04/05/2023

SOLVENT BASED

# YES WOOD PU SUEDE VARNISH 10



**Yes Wood Polyurethane Suede Varnish 10** is a hard-wearing single pack suede polyurethane modified alkyd varnish that provides a high quality suede finish to wood furniture & woodwork. It has been specifically formulated to provide scratch and water-resistant qualities for use on interior and exterior natural wood surfaces.

## USES

### Interior & Exterior

Ideal for use on all new or previously treated or coated interior & exterior wood furniture & woodwork where waxes, oils, varnishes or sealers may have been used. Use on tables, chairs, wood panelling, bar counters, doors & door frames, bannisters, stairs, decks, garage doors and low traffic floor areas.

## FEATURES & BENEFITS

- Mar and abrasion resistant
- Excellent resistance to heat, water, alcohol, food, fruit juices, grease, and detergents
- Excellent all-weather resistance and durability
- Excellent grain filling properties
- Lead content, less than 90 ppm

## TECHNICAL DATA

<b>PHYSICAL FORM</b>	Flammable viscous liquid containing pigments
<b>COLOUR</b>	Clear
<b>FINISH</b>	Smooth, Suede
<b>POLYMER TYPE</b>	Polyurethane modified alkyd resin
<b>PIGMENTS</b>	Weather and light resistant types only
<b>VISCOSITY AT 23 °C</b>	30 ± 10 sec FC4
<b>SG AT 23 °C</b>	0.90 ± 0.05 kg/ℓ
<b>SOLIDS</b>	By Mass = 42± 2%, By Volume = 34± 2%
<b>FILM THICKNESS</b>	WFT = 75 - 100 µm, and DFT= 25 - 35 µm
<b>SPREADING RATE</b>	Approximately 9.5 – 13.5 m <sup>2</sup> /ℓ per coat. Depending on the substrate condition and porosity
<b>DRYING PROPERTIES</b>	Surface or touch-dry: 4 hours @ 23°C. hard dry: 12 - 16 hour @ 23°C
<b>RECOATING TIME</b>	12 hours @ 23°C depending on WFT and conditions during drying
<b>PACKAGING</b>	5ℓ
<b>MIXING &amp; THINNING</b>	Stir the contents thoroughly with a flat paddle before use. Ready for use by paint brush or super fine roller application. If required to reduce viscosity, add a minimum quantity of mineral turpentine (NB: DO NOT add water) Recommended spray application viscosity for conventional and airless spray equipment: 17 - 20 Sec FC4 Mineral turpentine additions will vary for different applications

Toll Free: 0800 014 901 | Head Office: 012 804 7305 | [www.promacpaints.co.za](http://www.promacpaints.co.za)



# TECHNICAL DATA SHEET

W.DS.033 (FB-NC SERIES) REV04/05/2023

## CLEANING

Clean all tools (brushes, rollers, and spray equipment) while wet with mineral turpentine after use

## APPLICATION METHOD

Apply using a suitable brush, super fine roller and airless spray

## SURFACE PREPARATION

Thoroughly clean and prepare the wood surfaces by removing all dust, dirt, grease, grime and loose contaminants.

### SOLID TIMBER OR MEDIUM DENSITY FIBREBOARD (MDF):

**New surface:** Wood must be dry, clean, and free from any contamination.

Prior to application, sand the surface to a smooth finish with fine sandpaper, working in the direction of the grain. Round off any sharp edges. Ensure that the substrate is then free of dust by using dry compressed air or a lint free, clean cloth.

Suggested sandpaper grit:

- 150 - 180 grit sandpaper for raw wood
- 320 - 400 grit sandpaper for foil, melamine, filler-coated / primed substrates intermediate lacquer sanding

Fill surface defects, holes etc. using wood filler. Sand the surface of the wood with coarse sandpaper followed by progressively finer grades to produce a smooth surface. Remove all dust by blowing and wiping with a damp cloth. Leave to dry. Seal knots using a suitable knot sealer to prevent the possibility of resin bleeding into the varnish. Allow it to dry.

**Previously varnished, waxed, oiled or painted wood:** Wood must be dry, clean, and free from any contamination.

**Previously varnished wood in good condition:** Lightly abrade the surface with a 100 - 120 grit sandpaper to produce a matt effect, followed by progressively finer grades to produce the desired smooth finish. Remove dust using a damp cloth then allow drying.

**Previously varnished wood in poor condition:** Remove old varnish by stripping with Promac Paint Stripper, thereafter, rinse with clean water. Sand in the direction of the grain using 80 - 120 grit sandpaper, followed by progressively finer grades to produce the desired smooth finish. Remove dust with a dry, clean, lint free cloth, then wipe with mineral turpentine before the application of **Yes Wood Polyurethane Suede Varnish 10**.

**Previously waxed or oiled wood surfaces:** Mechanically remove evidence of residue and wipe down with lacquer thinners and a mutton cloth to remove any weathered material and restore the surface to an even appearance. Multiple wipes may be required. Treat as per new surface above.

**Previously painted wood surfaces:** Wood surfaces which are cracked, discoloured, weathered or flaking must be completely stripped back to bare wood, either by sanding or with Promac Paint Stripper. Wipe the surface down with lacquer thinners and mutton cloth and allow to dry. Sand smooth with 80 - 120 grit sandpaper, followed by progressively finer grades to produce the desired smooth surface. Remove dust with a dry, clean lint free cloth, then wipe with mineral turpentine before applying varnish.

### PLEASE NOTE THE FOLLOWING:

Sandpaper grits are a general recommendation and should be used as a guide only.

All additional products advised for use during surface preparation must be used & applied in accordance with that which is stated within the relevant product's data sheets.

## APPLICATION

### By brush or super fine roller:

Apply the first coat following a 1:1 dilution of the product with mineral turpentine. Allow at least 12 hours drying time. Sand the first coat lightly. Intermediate sanding of 600-800 grit sandpaper is recommended between coats of **Yes Wood Polyurethane Suede Varnish 10** to achieved the desired finish. Dust off with a damp cloth. Apply two to three coats to achieve the desired finish. The second and third coat should not be diluted!

## TECHNICAL DATA SHEET

W.DS.033 (FB-NC SERIES) REV04/05/2023

### By airless spraying:

Apply the first coat. If it is necessary to reduce viscosity, add a minimum quantity of mineral turpentine (NB: DO NOT add water). The recommended spray application viscosity for conventional and airless spray equipment is 17 - 20 Sec FC4. Allow at least 12 hours drying time. Sand the first coat. Intermediate sanding of 600-800 grit sandpaper is recommended between coats of **Yes Wood Polyurethane Suede Varnish 10** to achieve the desired effect. Apply two to three coats following the same procedure mentioned for the first coat.

### DO NOT USE

- If the temperature is below 10°C or above 40°C
- If the surface is damp (moisture reading above 10%)
- Surface temperature min 10°C and max 35°C
- If it is raining or rain is forecast within 6-8 hours
- Before 9h00 and after 16h00 in the winter

### HEALTH & SAFETY

Keep away from heat, sparks, open flames and hot surfaces. Prohibit smoking during use. Keep container tightly closed. Use only non-sparking tools. Take precautionary measures against static discharge. Do not breathe dust, fumes, gases, mist vapours or spray. Wash hands thoroughly after handling product. Wear protective gloves, clothing, eye protection and face protection. If swallowed, call your doctor.

### DISCLAIMER ADVICE

The information given in this Product Information Sheet is based on controlled laboratory tests and many years of experience. It is given in good faith, but no guarantee of any performance characteristic is given or implied. Promac paints cannot be held liable for consequential damage of whatsoever nature that may arise from the use of Promac products. Paint technology is continuously being developed and Promac Paints reserves the right to update product specifications without prior notice. Contact Promac Paints for further details.